

How do I turn off a Sennheiser Mic Transmitter?

Here are the steps:

1. Press the on/off button
2. Press the button shown as #2
3. Press the Set button #3
4. Press and hold the on/off button until it turns off

